

Taylor Cable Products, Inc.  
301 Highgrove Road  
Grandview, MO 64030  
(816) 765-5011

[www.taylorvertex.com](http://www.taylorvertex.com) / [info@taylorvertex.com](mailto:info@taylorvertex.com)



## 4-POLE MASTER DISCONNECT SWITCH #1033

### MOUNTING

1. Determine the mounting location for the switch following your sanctioning body guidelines.
2. Drill a 25/32" hole through the panel you are mounting to in order to accept the switch-mounting stem.
3. Remove the switch handle then remove the first nut and lock washer. Pass the switch through the hole in the panel and secure in place using the lockwasher and nut.
4. Apply the ON/OFF label.
5. Re-attach the switch handle.

### WIRING

1. Disconnect the positive and negative battery cables from the battery.
2. Make sure the switch is in the off position.
3. Connect the positive battery cable from the starter or starter solenoid to one of the 1/2" switch terminals on the switch (battery cable should be a minimum of 2-gauge wire).
4. (Optional) - Connect a jumper wire from the battery side 1/2" terminal to the 3/16" terminal on the switch.
5. (Optional) - Connect an accessory to the "Auxiliary" 3/16" terminal on the switch.
6. Connect the positive cable from the battery to the 1/2" stud on the switch.
7. Reconnect the positive and negative battery terminals; making certain the negative side of the battery is fastened to a clean ground.

